

2004 & EARLIER FLAT TOP WITH DOOR MOUNTED MIRRORS DROP VISOR INSTRUCTIONS

VERIFY the factory brackets are in the location listed below.
Remove factory visor and brackets. Drill out factory holes to 1/2"
Install new brackets in factory locations using supplied hardware.
Fasten visor skins to brackets using supplied hardware.

35051-IN
USE FOR 35051, 35051L, 35052

